

BOCAMODEM

V.34 DATA FAX



V.34 MODEM 28,800bps

New International Standard

Product Code:

MV.34I (Internal Model)

MV.34E (External Model)

Before You Begin your Installation

The product you have purchased is designed to be easily installed into most IBM PC or compatible systems. Many products have large, easy-to-read legends to allow for the easy configuring of the product. This installation manual contains detailed instructions. Most included software has automatic installation programs to place the software correctly onto your computer. However, as all computers are configured differently, you may be required to perform some basic DOS or Windows tasks. If you are not familiar with basic DOS commands such as DIR, CD, or EDIT, you should check your DOS manual, or seek assistance from your local computer dealer to install the product.



How to get Technical Assistance

The dealer that you purchased this product or your computer from is the first place you should go for technical assistance. The dealer is usually the most qualified source of help, and is most familiar with your system and how this product should be installed. Many dealers have customer service and technical support programs, with varying levels of support offered, depending on your needs and computer knowledge. *Please contact the dealer first whenever a problem occurs.*



If your Dealer Can't Assist you

If you can't get assistance from your dealer, the manufacturer provides varying levels of technical assistance as summarized on the following page.



Boca BBS
407-241-1601



**Standard Free
Technical Support**
407-241-8088



**Automated
Fax Retrieval
System**
407-995-9456



Priority Service
900-555-4900
(\$2 per minute)

The Standard Free Technical Support number is for quick answers to specific inquiries on product features and technical questions (call 407-241-8088; M-F, 8 am to 6:30 pm EST). Direct access to technical support representatives is provided on a limited basis. If you require immediate attention or in-depth help with the installation of the product, please call our 900-priority support number for service. This number gives you immediate access to senior-level technicians. The number is 900-555-4900. You will be charged \$2.00 per minute. The charges will appear on your next phone bill.

On-Line Support!

**CompuServe: GO BOCA
Internet:**

**email: support@boca.org
on the World-wide WEB:
<http://www.boca.org>**



Damaged or Missing Items

We use many world-class quality assurance programs to ensure the product you purchased is of the highest caliber. Sometimes, however, a component may be missing from the box, or is damaged or corrupt in some way. If this happens, immediately return the entire package to your place of purchase so you may exchange it for a new one. Your dealer should be able to provide you with an exchange far more quickly than by contacting us directly. If for some reason you are unable to return the product directly to its place of purchase, refer to the "Servicing Your Product" and "Warranty" sections in this manual for instructions.

Using the Boca Research V.34 MODEM manual.

This manual provides installation and operating instructions for the Boca **V.34 MODEM**. The manual assumes the user has basic computer skills and is familiar with personal computers. Its primary purpose is to provide physical installation instructions and basic troubleshooting. All sections should be read carefully before beginning any installation procedures. Our customer support experience has shown that many costly and time-consuming calls to our technical support staff can be avoided with closer attention to the information provided here. **In addition to following the instructions provided in this manual, you will also need to consult the documentation supplied with your communications software.**

IMPORTANT NOTICE

FCC Requirements

The Federal Communications Commission (FCC) restricts the way you can use modems. Read the FCC compliance statement found in Appendix D of this manual.

Connecting the Modem

You can connect the modem to various types of telephone jacks. The acceptable phone jack types are RJ-11, RJ-12, RJ-13, RJ-41S, and RJ-45S. Most homes and businesses use one of these jacks. If your phone system does not have a modular jack, you can purchase an adapter to convert your jack into an RJ-11C jack. Adapters may be purchased from any local phone or electronics store.

Copyright

©1995 Boca Research, Inc. All rights reserved. No reproduction of this document in any form is allowed without permission in writing from Boca Research, Inc. Boca Research is not liable for any damage resulting from technical or editorial errors or omissions contained in this document. The information in this manual is subject to change without notice. Revisions to the product(s) in this manual may occur at any time without notice.

Trademarks

All Boca Research products are trademarks of Boca Research, Inc. All other references to computer systems, software, and peripherals use trademarks owned by their respective manufacturers.

Publication Date: November, 1995


Printed in the U.S.A.

MV_34IE.PM5

Quick Start!

FOR THE EXTERNAL MODEL

If you are familiar with personal computers, modems, and the Windows operating systems, follow the diagram below to quickly connect the V.34 Modem to your system. Make all necessary connections as shown below.




After you have installed your modem and made the necessary connections, verify line connection by lifting your telephone receiver to check for a dial tone. After hearing the tone, hang up, power on your computer, and load your communications software. If you do not hear a dial tone, see *Section Four: Troubleshooting*.

Quick Start!

FOR THE INTERNAL MODEL

If you are familiar with personal computers, modems, and the Windows operating systems, follow the diagram below to quickly connect the V.34 Modem to your system. Make all necessary connections as shown below.



After you have installed your modem and made the necessary connections, verify line connection by lifting your telephone receiver to check for a dial tone. After hearing the tone, hang up, power on your computer, and load your communications software. If you do not hear a dial tone, see *Section Four: Troubleshooting*.

Contents

Quick Start	6
Section One: Introduction	10
Section Two: Installation (external)	13
2.1 The Contents of Your Package	13
2.2 Operational Requirements	14
2.3 Connecting the Phone Line	15
2.4 Preparing the System	16
2.5 Windows 3.1 Users	19
2.6 Windows 95 Users	20
2.7 Testing the Modem	22
2.8 Testing the Connection	24
Section Three: Installation (internal)	25
3.1 The Contents of Your Package	25
3.2 Communication Settings	26
3.3 Installing the Modem	28
3.4 Connecting the Phone Line	29
3.5 Windows 3.1 Users	31
3.6 Windows 95 Users	32
3.7 Testing the Connection	34
Section Four: Troubleshooting.....	35

Appendix A: Command and Protocol Overview..	40
Appendix B: Hardware Diagnostics.....	44
Appendix C: Technical Specifications	49
Appendix D: Compliance Information	50
Appendix E: Warranty Information	54
Appendix F: Servicing Your Product	55
Command Reference	58
Basic AT Commands	58
Extended AT Commands	62
MNP Operation	65
AT Commands for V.42/V.42bis	68
AT+MS (Modulation Select)	70
S-Registers	75
Result Codes	80
Glossary	85

Section One: Introduction

The V.34 protocol offers the newest technology allowing faster and more reliable connections between modems. The Boca V.34 modem is based on the Rockwell chip set. This modem supports the highest possible speeds today.

What this Means for You

You can make connections faster and transmit data at a minimum of *100% faster than with existing technology*. For example, remote networking users can work at speeds similar to that of cabled workstations, instead of experiencing time-lag while data crosses the phone line. The Boca V.34 modem lets you **SAVE TIME AND WORK SMARTER**.

Features

- Highest supported data transmission rates by the V.34 standard; 14.4Kbps send/receive fax.
- 100% compatible with the Hayes 'AT' command set.
- Auto-dial and auto-answer; tone or pulse dialing.
- Group III send and receive fax capability with support for Class 1 and Class 2 fax commands.
- Communication ports selectable as COM1, 2, 3, or 4 using interrupts 3, 4, 5, or 7 (**INTERNAL ONLY**).

- DTE speed up to 115.2Kbps, 16550A UART interface (internal), serial CCITT V.24 (EIA/RS-232-D) (external).
- Supports V.42/MNP2-4 error control and V.42bis/MNP5 data compression for throughput up to 115.2Kbps

Installation Hints

Your BOCAMODEM has been pre-set at the factory for optimum performance. All defaults are set to allow the modem to negotiate the best possible connection with highest quality, data compression, and error correction. Because of these factory defaults, the suggested initialization (INIT) string is: **ATZ**. You should change the INIT string in all of your software packages to this INIT string.

If you want to custom configure your stored profiles, we suggest that you always start out with an **AT&F&C1&D2-K0** before customizing other commands. This string will reset the modem to the factory defaults as well as reset some other basic settings. If modem performance suffers after modifying settings, send the INIT string above (AT&F...-K0) to the modem.

Notes on Performance

To get optimum performance from your V.34 BOCAMODEM, the phone line quality over which you are transmitting and receiving must be reliable and relatively free of "noise".

HOW THIS MANUAL IS ORGANIZED

Quick Start. If you are familiar with modem operations, this abbreviated procedure provides a short cut for connecting the Boca V.34 Modem. Otherwise, read Section Two or Three before continuing.

Section One: Introduction. An overview of the features of the Boca V.34 Modem.

Section Two and Three: Installation. These sections provide communication settings (**internal** only), a diagram of the V.34 Modem board or external unit, physical installation instructions (including how to connect the phone line), and procedures for testing the connection.

Section Four: Troubleshooting. This provides a description of the most common problems which may be encountered during installation and operation along with possible solutions.

Appendices. These include:


- technical specifications,
- FCC and DOC (Canada) compliance information,
- warranty policies,
- how to service your Boca product if necessary
- a brief survey of standard and extended AT command sets, S-registers, and high-level protocols,
- hardware diagnostics
- glossary

Section Two: Installation (External Model)

This section explains how to connect the Boca Research V.34 Modem to your computer.

2.1 The Contents of Your Package

Verify that your modem package contains the following items:




If any items are missing or damaged, contact the vendor from whom you purchased the modem for assistance.

2.2 Operational Requirements

The V.34 Modem has few requirements and is easy to use. Be sure to read the information in the Appendix about connecting to the phone company. In addition, note the following:


- The communication settings are controlled by the software that manipulates the serial interface present in your system. The external modem is connected to that interface.
- Operating the V.34 Modem with a computer requires communication software, either as a stand-alone product as included here, or as part of an application program.
- The V.34 Modem takes a DB-25 (25-pin male connector), but computer equipment varies. Check the serial ports at the rear of your system.
- The V.34 Modem uses an existing serial port (9- or 25-pin connector) on the back panel of your computer. You will need a 25-pin serial cable to attach to the RS-232 serial port connector on the back of the modem.



2.3 Connecting the Phone Line

An RJ-11 cable is provided with the purchase of your V.34 Modem. This section contains information you will need before you connect the telephone line to the V.34 Modem and explains how to make the proper connections from the V.34 Modem to your telephone line.


Before you connect the telephone line to the V.34 Modem, you should familiarize yourself, if you haven't done so already, with the information provided in the Appendix of this manual concerning FCC and telephone company requirements.




2.4 Preparing the Modem

Follow these simple steps to connect the modem to your computer:


1. Turn off your computer and all peripheral devices.
2. Examine the back of the modem and review the attached interfaces as shown above.
3. Check to make sure that the power switch is OFF (DOWN). Then plug the small end of the power adapter into the power jack on the back of the modem and plug the power adapter into a standard 120V AC wall socket.




4. Disconnect your present phone cord from the wall jack. Plug the end of the phone cord that came with the modem into the wall jack, and the other end into the RJ-11 jack at the rear of the modem marked **LINE**.



If you want to keep your telephone connected for conventional calls, plug its cord into the other jack at the rear of the modem labeled **PHONE**.



5. Lastly, connect the modem to the computer's serial port with the serial cable. The modem is now ready to be tested and operated. Turn your computer on now, then switch ON the modem (switch in the UP position).





2.5 Windows 3.1 Users

1. Run COMCHECK to ensure that your system sees the modem. Insert the diskette containing the COMCHECK program and type: **A:\COMCHECK** or **B:\COMCHECK**.

COMCHECK will automatically start Windows. If you have another application that starts when you run Windows, you will have to close it now in order to view COMCHECK. Follow the on-screen instructions.

NOTE: You must have the Modem switch turned on (up position) for COMCHECK to detect the modem.

2. Insert the diskette containing the communications software and from the Windows File Menu, select Run...Then type **A:\SETUP** (or **B:\SETUP**) and follow all on-screen instructions. Refer to the communications software manual should you need assistance.



2.6 Windows 95 Users


1. Click on the Control Panel....

Select **Modems**...if there are no modems installed in your computer, and go to step 2.

If there is a modem installed, a Modem Properties screen is displayed. Select **Add**...

2. Make sure the following option is checked: "Don't Detect my modem; I will select it from a list".

3. From the Install New Modem screen, choose "Boca Research" as a modem manufacturer. Then select the model ("Boca 28.8Kbps V.34 MV.34E").



4. Select your modem. Then select **Next....** Specify the COM port setting chosen when you installed your high-speed serial card. Then select **Next....** These settings must match.
5. Select **Finish**. Continue with the next page to test the modem.

NOTE: In order to get optimum performance from the external V.35 modem, you will need to have a 16C550/50 UART chip on your serial port. Without the 16C550/50 UART, errors may result while uploading and downloading. If necessary, contact your dealer for information on Intel's serial I/O products.

2.7 Testing the Modem

To verify that your modem is working properly, follow these steps:

After making sure your communications software is loaded and started, you are ready to test the modem's connection. Note the status indicators as explained on the following page, then continue with 2.8.

NOTE: In order to get optimum performance from the external V.34 modem, you will need to have a 16C550/650 UART chip on your serial port. Without the 16C550/650 UART, errors may result while uploading and downloading. If necessary, contact your dealer for information on Boca's serial I/O products.

Indicator	Definition	Status
TM	Test Mode	FLASHES when modem is in test mode and if any errors are detected.
AA	Auto Answer	ON when in Auto Answer mode and when online with the host modem.
HS	High speed	ON when the V.34 Modem is powered on or communicating with another modem at 4800bps or faster.
OH	Off Hook	ON when the V.34 Modem takes control of the telephone line to establish a data link.
SD	Send Data	FLASHES when a data bit is sent to the V.34 Modem by the computer.
RD	Received Data	FLASHES when a data bit is received from the phone line, or when the modem sends result codes to the computer.
TR	Terminal Ready	ON when the modem receives a data terminal ready signal from the computer via the RS-232 cable.
CD	Carrier Detect	ON when the modem receives a valid data signal (carrier) from a remote modem. Ready for data transmission.

2.8 Testing the Connection

1. If you are using a telephone, check for a dial tone using the telephone handset. If a dial tone is heard, continue with the next step. If you do not hear a dial tone, check the connections you made in 2.4 Preparing the Modem, or refer to *Troubleshooting (Section Four)*.
2. Your communications software should already be loaded as instructed in 2.5 or 2.6. Most communications programs when started are in command mode. Refer to the program's documentation for additional information.
3. Type in the command **ATZ** followed by **ENTER** and the V.34 Modem will respond with OK. If the V.34 Modem does not respond with OK, refer to the Troubleshooting section of this manual.
4. Start your communications software and enter terminal mode; AT commands typed in at the DOS prompt will result in a "Bad command or file name" message. Type **ATH1** followed by **ENTER** and you should hear a dial tone from the speaker on the modem.
5. Type **ATH** followed by **ENTER** to put the modem on hook. This confirms that the V.34 Modem has been successfully installed into the computer.
6. Your V.34 Modem is now ready for use. Continue now with your communications software and documentation.


ATZ
OK
ATH1
OK
ATH
OK

Section Three: Installation (Internal Model)

This section explains how to install the Boca Research internal V.34 Modem in your computer.

3.1 The Contents of Your Package

Verify that your modem package contains the following items:




If any items are missing or damaged, contact the vendor from whom you purchased the modem for assistance

3.2 Communication Settings

The V.34 Modem can be configured as COM1, COM2, COM3, or COM4. The default setting for the modem is COM3 using IRQ5. The modem cannot share the same interrupt with any other device.

One way to avoid interrupt-sharing is to select a non-standard interrupt (i.e., IRQ) if it is available, such as IRQ5. However, the communications software must be able to select this non-standard interrupt as well.

1. Run COMCHECK to determine how many serial ports are already installed in your system. Insert any diskette into your floppy drive and type: **A:\COMCHECK** or **B:\COMCHECK**. Follow all on-screen instructions.
2. Remove the V.34 Modem from its anti-static bag, handling it by its edges and metal retaining bracket. Be careful not to touch the edge connector or any components on the modem card. If necessary, change the jumpers on the modem for the next available port based on directions from COMCHECK. See the illustration on the next page for assistance in jumper settings.




Your modem has been given a default setting of COM3/IRQ5. Frequently in today's systems, COM1 and COM2 have already been assigned to other devices. Make sure you run the COMCHECK program which came with the modem to avoid conflicts with other devices already in your system. Insert any diskette into your floppy drive and type:

A:\COMCHECK or
B:\COMCHECK

WINDOWS 3.1 USERS:

When an internal modem uses non-standard setting such as COM3/IRQ5, you must go into Windows Control Panel and change the address settings.


Select Ports..., then Settings..., then Advanced. Make sure COM3 is set to a Base I/O Port Address of 03E8 and the IRQ is set to IRQ5.



3.3 Installing the V.34 Modem

This subsection provides step-by-step instructions for installing your internal V.34 Modem.

1. Power off your computer and disconnect any attached devices and power cords.
2. Remove the computer's cover and locate an available 8- or 16-bit expansion slot. Remove that expansion slot cover and save the screw.
3. Carefully insert the modem into the expansion slot applying pressure to the upper metal edge until snaps into place.




4. Secure the modem card into place by aligning its metal retaining bracket with the hole in the top edge of the system's rear panel. Fasten the metal bracket with the screw removed earlier from the expansion slot cover.
5. Replace the system cover.

3.4 Connecting the Phone Line


An RJ-11 cable is provided with the purchase of your modem. This sub-section contains information you will need before you connect the telephone line to the modem. It also explains how to make the proper connections from the modem to your telephone line.

Before you connect the telephone line to the modem, you should familiarize yourself, if you haven't done so already, with the information provided in the Appendix of this manual concerning FCC and telephone company regulatory requirements.

1. Make sure that your computer is still powered down. Plug either end of the RJ-11 cable provided with the modem into the **LINE** jack on the modem board.



2. If a phone is connected to the telephone wall jack, unplug the phone cable. Then plug the other end of the modem cable into the telephone wall jack.
3. To continue using the phone, connect the phone cable into the **PHONE** jack on the modem board.





3.5 Windows 3.1 Users

1. Run COMCHECK a second time to verify the installation of your modem. Insert the diskette containing the COMCHECK program and type:
A:\COMCHECK or B:\COMCHECK.

NOTE: If Windows automatically boots up an application when your computer is turned on, you must close that application before the COMCHECK Installation Screen can be viewed.

2. Follow the on-screen instructions. COMCHECK will automatically start Windows to allow the installation of your communications software. You may install the software at this time or you may use your existing communications software.
3. To install your communications software without running COMCHECK, insert the appropriate diskette and from the Windows File Menu, select Run. Then type **A:\SETUP** (or **B:\SETUP**) and follow all on-screen instructions.



Refer to the communications software manual should you need assistance. The software will test your modem as part of the software installation process.

3.6 Windows 95 Users

1. Select **Start... Control Panel... Add New Hardware....**
2. Continue selecting **Next...** to allow Windows 95 to detect the new hardware in your system and check **Yes** after hardware detection.
3. Select **Details....** Then select **Communications Port....**
Windows 95 should have found a communications port. If not, verify the modem has been physically installed with no conflicts.


NOTE: If you need to reconfigure the board, re-select **Control Panel... System... Device Manager**. Refer to your Windows 95 documentation on changing properties of devices using the Device Manager.

4. Select **Finish**.
5. Return to the **Control Panel...**

Select **Modems...if there are no modems installed in your computer**, and go to step 6.

If there is a modem installed, a Modem Properties screen is displayed. Select **Add...**

6. Make sure the following option is checked: "Don't Detect my modem; I will select it from a list".
7. From the Install New Modem screen, choose "Boca Research" as a modem manufacturer. Then select the model ("Boca 28.8Kbps V.34 MV.34I").



8. Select your modem. Then select **Next....** Select the COM port setting chosen in section 3.2 in the manual. Then select **Next....** These settings must match.
9. Select **Finish.**

3.7 Testing the Connection

1. Power on the computer.
2. If you are using a telephone, check for a dial tone using the telephone handset. If a dial tone is heard, continue. If you do not hear a dial tone, check the connections you made in the previous subsection, or refer to *Troubleshooting (Section Four)*.
3. Install your communications software and place it in command mode. Refer to the software manual for additional information.
4. Start your communications software and enter terminal mode; AT commands typed at the DOS prompt will result in a "Bad Command or File Name" message. Type in **ATZ** followed by **ENTER** and the modem will respond with OK after a few seconds. If the modem does not respond OK, refer to Troubleshooting (Section Four).
5. Type **ATH1** followed by **ENTER** and you should hear a dial tone from the modem speaker. To adjust speaker volume, refer to your communications software, or use the **ATL** command.
6. Type **ATH** followed by **ENTER** to put the modem "on-hook". This confirms that the modem has been successfully installed into the computer.
7. Your V.34 internal modem is now ready for use. Continue now with your communications software and documentation.

ATZ
OK
ATH1
OK
ATH
OK

Section Four: Troubleshooting

This section lists common problems that may be encountered and their possible solutions.

SYMPTOM	POSSIBLE REMEDY
No dial tone.	<ul style="list-style-type: none">■ Verify that you have cables plugged in correctly as instructed in Section Two or Three.■ Connect a telephone set directly to the wall jack and check for a dial tone. If no dial tone is heard, the telephone line is not working. Contact the telephone company.
Modem will not connect to another modem.	<ul style="list-style-type: none">■ Check the connections between the modem and the computer, and the modem and the telephone line.■ Make sure the telephone jack is operational as described above.■ The telephone line may be in use at a different extension.■ Perhaps the number you have called does not reach a modem, or the remote modem may not be set up to respond.
No response when you type in AT commands	<ul style="list-style-type: none">■ There may be a conflicting port address. Re-configure the modem's COM port address (INTERNAL MODEL ONLY).

SYMPTOM	POSSIBLE REMEDY
No response when you type in AT commands (contd)	<ul style="list-style-type: none">■ Verify that the communication software is set to the same communications port where your modem is attached (e.g., COM1, COM2). Check IRQ settings in your software and on the modem.■ Check your serial cable connection (EXTERNAL MODEL ONLY).■ Try typing AT&F to reset the modem to its factory defaults.■ Move the modem to another serial port (<i>power down the host computer first</i>). If the modem works after being moved, it's likely the problem is not with the modem.
AT commands not visible.	<ul style="list-style-type: none">■ Make sure the echo command is set to ON. Change to echo with the ATE command.
After data connection is established, data is displayed as garbled characters.	<ul style="list-style-type: none">■ Make sure the local (yours) and remote modem configurations are compatible.■ Turn off your modem (EXTERNAL), exit, and re-run your communication software.■ Verify that both modems are operating with the same settings, speed, data, parity, and stop bits.■ The software may not be set for correct terminal emulation. Configure software to correct type. ANSI terminal emulation is most commonly used.

SYMPTOM	POSSIBLE REMEDY
Garbled characters (contd)	<ul style="list-style-type: none">■ Power down your system (INTERNAL) and re-run your communications software. Check software settings.■ Exit the communications program and restart it.
The modem does not answer an incoming call.	<ul style="list-style-type: none">■ You may not have enabled auto-answer. Use your software to enable this function.■ If you have an answering machine, it may be answering before the modem can. Turn the answering machine off, or, use the software to set auto-answer to respond in fewer rings than the answering machine.
Modem disconnects while on-line.	<ul style="list-style-type: none">■ Check for any loose connections.■ Re-try the connection by dialing the number several times. You may be experiencing line interference.■ An incoming call may have broken the connection if a call-waiting feature was enabled. Disable call-waiting and try again.

SYMPTOM	POSSIBLE REMEDY
I am having trouble getting my init string to work.	<ul style="list-style-type: none">■ Init strings are primarily personal preferences. Use the most basic one that can get the job done. See Installation Hints, page 11. An &Q6 (which disables error control) is optional.
Connection Errors	<ul style="list-style-type: none">■ Try connecting at a lower speed (e.g., 9600 or 2400bps).■ Turn off error correction/compression with an AT&Q6%C0 command.■ Noisy/poor line conditions may prohibit connection. Have your phone company test your lines.■ Verify that the modem at the other end is up to date and compliant with current CCITT and Bell standards.

SYMPTOM	POSSIBLE REMEDY
Problem Connecting to On- line subscription services.	<ul style="list-style-type: none">■ Some on-line services require that your modem be configured to run with error correction and data compression turned OFF. The easiest way to accomplish this is by using the command AT&Q6 and setting the communication software to the correct baud rate for the service you are calling (e.g., 2400, 9600bps). If you still have problems connecting, try forcing the modem to connect up at the slower speed with the commands AT&Q6N0S37=6 for 2400 baud, and AT&Q6N0S37=9 for 9600 baud services.
Download terminates abnormally.	<ul style="list-style-type: none">■ Make sure the AT&R1 is set in your active profile.

Appendix A: Command/Protocol Overview

In most cases, your communications software will set and control the operation of your modem. Following is a brief survey of the most commonly used Hayes-compatible AT commands for use with your modem. In addition, we've also provided information on extended AT command sets, S-Registers, and commands and registers for high-level protocols such as MNP, V.42/V.42bis, and V.32/V.32bis.

It will rarely be necessary to use 'AT' commands and S-Registers in command mode. We include them here for more advanced users who may prefer command mode operation, or require special settings. See pages 58-84 for additional details.

Hayes-compatible commands consist of a basic command set and an extended command set. The basic set involves functions such as dialing a number, or putting the modem on-hook (i.e., replacing the telephone handset).

Extended commands allow more sophisticated control of the modem such as transmission speed, or initiating high-level functions like data compression or error correction. These functions are defined and controlled by the available protocols mentioned above. A protocol is a set of standards by which data communications operate.

Every AT command includes an "AT" prefix, followed immediately by the command and, in many cases, additional parameters. Multiple commands can be entered at the same time from your communications software.

**AT Command[parameter] [parameter] ...
PRESS ENTER**

Example: ATH or ATH0 tells the modem to disconnect

Extended commands were developed to provide greater functionality and control over modem operations. Their format is the same as the basic command except that an additional parameter is required following the AT prefix and before the numerical parameter. This additional parameter comes in three different forms:

the <i>ampersand</i> (&) character:	extended AT command
the <i>backslash</i> (\) character:	extended AT command for MNP
the <i>percent</i> (%) character:	extended AT command for V.42/V.42bis

Examples: AT&V tells the modem to display (view) its current configuration and user profile.

AT\G1 enables flow control. Flow control compensates for the difference between the rate at which data reaches a device and the rate at which the device processes and transmits.

AT%E1 tells the modem to monitor line quality and request a "retrain" (adjustment) to the connection.

S-Registers

Modem command "language" also employs a set of indicators or registers, which are various numerical values all with a standard "S" prefix, hence S-Registers. To a large extent, the values defined in the S-Registers regulate the operation of the modem and the function of some commands in the AT command set.

Example: S-Register 6, or $S6=n$, defines the length of time the modem will wait for a dial tone. In this case the acceptable range is 3-6 (in seconds) with a default value of 5. With $S6=3$, the modem will wait three seconds for a dial tone when going off-hook before dialing the first digit of its telephone number.

Data Communication Protocols

This can be more than a little confusing. These protocols represent various domestic and international standards which enhance modem performance and reliability. The protocols are activated and controlled by a variety of extended AT commands and S-Registers.

MNP stands for Microcom Networking Protocol and is a protocol developed by Microcom for full-duplex, error-free communications. This protocol detects and corrects errors which can result from telephone line noise and other signal distortions. There are several classes of MNP operation also referred to as service classes. Class 5 maximizes data transfer rate and provides compression which can significantly increase data throughput.

The "V-Dot" standards are more numerous, but have a single origin: the International Telecommunications Union Telecommunications Standards Sector (formerly the Consulting Committee for International and Telephone and Telegraph or CCITT). Some of the lower-level standards such as V.21 and V.22 have "domestic" equivalents as developed by the former Bell System, also referred to as Bell standards. The "V-Dot" standards may be summarized as shown on the following page.

- V.21** The CCITT standard for 300bps communications. Domestic modems follow the Bell 103 standard, but V.21 can accept international calls at 300bps.
- V.22** The CCITT standard for 1200bps communications. The domestic equivalent is the Bell 212A standard.
- V.22bis** The CCITT standard for 2400bps.
- V.23** CCITT for 1200bps with a 75bps back channel. This is mostly used in Europe and South America.
- V.24** CCITT serial interface standard (EIA/RS232-D).
- V.32** CCITT standard for 9600bps and 4800bps communications.
- V.32bis** CCITT standard for an extensive range of high-speed modems operating at 14,400bps, 12Kbps, 9600bps, 7200bps, and 4800bps.
- V.42** CCITT standard for detection and negotiation for LAPM (Link Access Procedure for Modems) error control. V.42 will also support MNP levels 2-4.
- V.42bis** An extension of V.42 specifying the data compression protocol for use with V.42.
- V.FC** A Rockwell International-sponsored protocol. It can operate up to 28,800bps for data and 14,400bps for send/receive fax.
- V.34** ITU-TSS protocol. It can operate up to 28,800bps for data and 14,400bps for send/receive fax.

Appendix B: Hardware Diagnostics

The V.34 modem includes several tests which evaluate the operation of the modem, its connection to the local DTE, and the communications link between the local and remote modems. Use of these tests requires setup of internal registers and may also require the use of two modems and a central office line simulator. **A thorough knowledge of modem operation and registers is needed for their use and should not be undertaken lightly.**

Local Analog Loopback Test

This test verifies the path between the local modem and the PC.

1. Set the DTE speed from 1200 to 28,800 bits per second. If the speed is less than 1200 or greater than 28,800 the test **WILL NOT** operate and a result code of ERROR will be generated if any tests are attempted.
2. Make sure the modem is in command mode (no connection made).
3. Issue an AT&Q0 command to the modem. This sets the modem to the direct mode.
4. Set the timer register (S18) for desired test time (in seconds). Example: "ATS18=10" provides for a 10 second test.

5. To begin the test, type AT&T1 [ENTER]. The modem should respond with a CONNECT message.
6. After the number of seconds specified in S18, the modem will terminate the test and respond with "OK".

Local Analog Loopback Test with Self-Test

This test verifies the integrity of the local modem's transmit and receive circuits.

1. Set the DTE speed from 1200 to 28,800 bits per second. If the speed is less than 1200 or greater than 28,800 the test **WILL NOT** operate and a result code of ERROR will be generated if any of the tests are attempted.
2. Make sure the modem is in command mode (no connection made).
3. Issue an AT&Q0 command to the modem. This sets the modem to the direct mode.
4. Set timer register (S18) for desired test time (in seconds). Example: "ATS18=10" provides for a 10 second test.
5. To begin, type AT&T8 [ENTER]. The modem responds with OK.
6. After the number of seconds specified in S18, the modem should respond with 000 (meaning 0 errors were found during the self test).

Remote Digital Loopback Test

1. Set the DTE speed from 1200 to 28,800 Bits per second. If the speed is less than 1200 or greater than 28,800 the test **WILL NOT** operate and a result code of ERROR will be generated if the test is attempted.

The baud rate is also limited to the highest baud rate supported by the telephone line (28,800bps modulation is possible if the telephone line is without distortion and noise free). If the telephone line has problems, bring the baud rate down to 9600 or 2400. If the line quality is too poor, use a line simulator to run this test.

2. Issue an AT&Q0 command to the local modem. This sets the modem to the direct mode.
3. Issue an AT&Q0 command to the remote modem, also setting it to the direct mode.
4. Issue an AT&T4 to the remote modem. This instructs the remote modem to grant a request for a remote digital loop back test.
5. Issue an ATS0=1 to the remote modem which allows it to auto-answer the incoming call.
6. Set the timer register (S18) of the local modem for desired test time (in seconds). Example: "ATS18=10" provides for a 10 second test.

7. Issue a dial command to the local modem to instruct it to call the remote modem. Wait until the two modems have established a connection.
8. Type the escape sequence +++ to revert to command mode. The modem will respond with OK.
9. To start the test, type AT&T6 [ENTER]. The modem will return a CONNECT response if the loopback data link has been successfully completed, and an ERROR response if the link has failed. If a CONNECT response was received, key in a text message and it will echo on the screen.

Remote Digital Loopback Test with Self-test

1. Set the DTE speed from 1200 to 28,800 bits per second. If the speed is less than 1200 or greater than 28,800 the test **WILL NOT** operate and a result code of ERROR will be generated if the test is attempted.

The baud rate is also limited to the highest baud rate supported by the telephone line (28,800 is possible if the telephone line is without distortion and noise free). If the telephone line has problems, bring the baud rate down to 9600 or 2400. If the line quality is too poor, use a line simulator to run this test.

2. Issue an AT&Q0 command to the local modem. This sets the modem to the direct mode.

3. Issue an AT&Q0 command to the remote modem, also setting it to the direct mode.
4. Issue an AT&T4 to the remote modem. This instructs the remote modem to grant a request for a remote digital loop-back test with self test.
5. Issue an ATS0=1 to allow the remote modem to auto-answer the incoming call.
6. Set timer register (S18) of the local modem for desired test time (in seconds). Example: "ATS18=10" provides for a 10 second test.
7. Issue a dial command to the local modem to instruct it to call the remote modem. Wait until the two modems have established a connection.
8. Type the escape sequence (++++) to revert to the command mode. The modem will respond with OK.
9. Type AT&T7 [ENTER] to initiate the remote digital loopback test. The local modem will send a test pattern to the remote modem. This pattern will not be visible on the screen.
10. The modem will then send a three-digit value, indicating the number of errors detected during testing. If the result is 000, no errors were found.

Appendix C: Technical Specifications

Modem Data Rate: 28.8K, 26.4K, 24K 21.6K, 19.2K, 16.8K, 14.4K, 12K, 9600, 7200, 4800, 2400, 1200, or 300bps

Fax Data Rate: 14.4K, 12K, 9600, 7200, 4800, 2400bps

Protocol Compatibility:

CCITT: CCITT: V.34 (28.8Kbps), V.32bis (14.4Kbps), V.32 (9600bps), V.42, V.22 (2400bps), V.21 (1200bps)

Bell: Bell 212A (1200bps), Bell 103 (300bps)

Rockwell: V.FC

Fax Modulation Protocols

V.17 (14.4Kbps) transmit and receive
V.29 (9600/7200bps) transmit and receive
V.27 ter (4800/2400bps) transmit and receive
V.21 channel 2 (300bps) transmit and receive

V.42/MNP2-4 and V.42bis/MNP5 support

LED Status Indicators:
(EXTERNAL)

TM, AA, HS, OH, SD, RD, TR, CD

Diagnostics:

- Local/remote digital and analog loopback.
- Automatic power-on self-test.

Dimensions:

EXTERNAL: 7 1/4" x 5 3/8" x 1 1/4"

INTERNAL: 4 1/4" x 4 1/8"

Operating Temperature Requirements:

Dry Bulb Temperature:	10-40° C (50-104° F)
Relative Humidity:	8-80%
Storage:	1-60° C (33.8-140° F)

Appendix D: Compliance Information

FCC Statement:

"This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received including interference that may cause undesired operation.

THIS UNIT COMPLIES WITH FCC PART 68 AS OF DATE OF MANUFACTURE.

This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to Part 15 of FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antennae.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to insure compliance.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment."

Notification to the Telephone Company

Notification to the telephone company is no longer required prior to connecting the registered equipment but upon request from the telephone company the user shall tell the telephone company which line the equipment is connected to as well as the registration number and the ringer equivalence of the registered protective circuitry. In most, but not all areas, the sum of all RENs should be 5.0 or less. The FCC Registration number and Ringer Equivalence number are printed on the main chip in the center of the internal modem board, or on the underside of the external modem.

Malfunction of the Equipment

In the event that the MODEM should fail to operate properly, the customer shall disconnect the equipment from the telephone line to determine if it is the customer's equipment which is not working properly, or if the problem is with the MODEM, the user shall discontinue use until it is repaired. In the event service is needed the user should contact the vendor from whom you purchased the MODEM.

Telephone Connection Requirements

Except for telephone company-provided ringers, all connections to the telephone network shall be made through standard plugs and standard telephone company-provided jacks, or equivalent, in such a manner as to allow for easy and immediate disconnection of the terminal equipment. Standard jacks shall also be arranged that, if the plug connected thereto is withdrawn, no interference to the operation of the equipment at the customer's premises which remains connected to the telephone network, shall occur by reason of such withdrawal.

Incidence of Harm

Should terminal equipment or protective circuitry cause harm to the telephone network, the telephone company shall, where practical, notify the customer that temporary discontinuance of service may be required; however, where prior notices are not practical, the telephone company may temporarily discontinue service if such action is deemed reasonable in the circumstances. In the case of such temporary discontinuance, the telephone company shall promptly notify customers and will be given the right to bring a complaint to the FCC if they feel the disconnection is not warranted.

Changes in Telephone Company Equipment or Facilities

The telephone company may make changes in its communications facilities, equipment, operations, or procedures, where such action is reasonably required and proper in its business. Should any such changes render the customer's terminal equipment incompatible with the telephone company facilities, the customer shall be given adequate notice to make modifications to maintain uninterrupted service.

General

The FCC prohibits customer-provided terminal equipment be connected to party lines or to be used in conjunction with coin telephone service.

Installation

The MODEM is equipped with a USOC RJ-11 standard miniature modular jack and is designed to plug directly into a modular jack.

DOC Compliance Statement (Canada)

The Canadian Department of Communications label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunction, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure, for their own protection, that the electrical ground connections of the power utility, telephone lines, and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

CAUTION Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority or electrician, as appropriate.

The Load Number (LN) assigned to each terminal device denotes the percentage of the total load to be connected to a telephone loop which is used by the device to prevent overloading. The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the load numbers of all the devices does not exceed 100. The Load number appears on the underside of the V.34 Modem.

To be installed in UL-listed and CSA-certified computers with instructions on how to add/remove expansion cards.

Appendix E: Warranty Information

Limited Warranty

Boca Research, Inc. (BRI) warrants to the original buyer of this BRI product that the hardware is free of defects in materials and workmanship for a period of five (5) years from the date of purchase from BRI or its authorized dealer. Should the product fail to be in good working order at any time during the five-year period, BRI, will at its option, repair or replace this product as described below. This warranty does not cover defects resulting from misuse, abuse, negligence, accident, repairs, or alterations made by either the customer or another party. Boca Research reserves full rights to determine whether a defective product falls into this category.

The entire risk as to the quality and performance of the product rests with the customer. Any written or oral information or advice given by Boca Research dealers, distributors, agents, or employees will in no way increase the scope of this warranty. This warranty applies only to the product described in this manual and not to any other value-added software which may be included.

All products will be serviced and returned via UPS-ground at no charge to customers.

All customers are required to demonstrate proof of purchase when requesting a Return Merchandise Authorization (RMA). The period of service commences on the date of purchase. A copy of the sales slip must be included with the returned merchandise.

Products which require Limited Warranty service during the warranty period should be delivered to BRI at the address in the Appendix (Servicing Your Boca Product) with proof of purchase and the Return Merchandise Authorization (RMA) number provided by BRI Technical Support. Refer to the Appendix in your manual. Replacement parts or complete products will be furnished on an exchange basis only. Replaced parts and/or products become the property of BRI.

If the returned product is sent by mail, the purchaser agrees to prepay shipping charges, insure the product or assume the risk of loss or damage which may occur in transit, and to use a shipping container equivalent to the original packaging. ALL EXPRESS AND IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS OF PURPOSE FOR THE PRODUCT ARE LIMITED IN DURATION TO THE ABOVE FIVE- AND ONE-YEAR PERIODS, RESPECTIVELY.

UNDER NO CIRCUMSTANCES (WHETHER BASED IN CONTRACT OR TORT) SHALL BOCA RESEARCH BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS AS A RESULT OF THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR DISRUPTION OF ITS PRODUCTS.

Boca Research reserves the right to make periodic changes or enhancements to any Boca Research product without prior notification, but has no obligation to modify or update products once sold.

This warranty gives you specific legal rights, and you have other rights which may vary from state to state. This warranty is valid only in the United States.

Appendix F: Servicing Your Boca Product

If your V.34 Modem requires service, first contact the authorized dealer from whom you purchased the modem. If the dealer is unable to assist you, and you must contact Boca Research, Inc., please follow the instructions below.

Our electronic BBS is available 24 hours a day at (407) 241-1601 and will support data transmission speeds up to 28.8Kbps with settings of N, 8, 1. Once your modem is functional, the BBS may be helpful (especially during off hours) if you have a question about product settings, or if you wish to download special software or utilities.

If the Troubleshooting section (section Four) did not resolve your problem, you may call our technical support staff for assistance. If you haven't referred to the Troubleshooting section, do so now.

NOTE: CALLING TECHNICAL SUPPORT WITHOUT COMPLETE AND ACCURATE INFORMATION CONCERNING YOUR PROBLEM MAY BE BOTH TIME-CONSUMING AND FRUSTRATING FOR YOU.

1. When calling Boca Research Technical Support, have the following information available:

- **Board or external unit name and part number**
- **Computer manufacturer**
- **Computer Model**
- **Peripherals in system**
- **Operating system and version**

If you suspect a problem with a specific program or software package, make note of the name, version or release number, and manufacturer of the software.

2. Call our Technical Support Department between the hours of 8:00 a.m. and 6:30 p.m. EST Monday through Friday at (407) 241-8088. A technician will be available to discuss the problem(s) you are experiencing.

If factory service is required, you will be given a Return Merchandise Authorization (RMA) number. Please place this number on the outside of the package when you return the item(s) for service and reference it on any correspondence included in the package. Boca Research, Inc. will return any product which is not accompanied by an RMA number.

3. Refer to the Warranty Statement if the product is covered under the five-year Boca Research, Inc. Limited Warranty.
4. Certain parts will not be covered under the Boca Research, Inc. Limited Warranty. Dealer installed parts are warranted by the dealer. Parts which you have installed yourself are covered only by the supplier's warranties. In these cases, Boca Research, Inc. can identify which parts are defective, but will not replace such parts until specific written authorization is received from you. The cost of parts and labor involved in making such repairs will be billed to you C.O.D.
5. When sending the V.34 Modem to Boca Research, Inc. for repairs, please be sure to include:

- the V.34 modem (board or external case only)
- a copy of the original invoice
- your return street address (for UPS purposes)
- phone number
- the RMA number mentioned above

Package the product securely in a container equivalent to the original packaging, and insure the package to protect against loss or damage during transit. Shipping charges must be prepaid; C.O.D. shipments will not be accepted. Please use the address below for all correspondence:

Boca Research, Inc.
RMA Department - RMA # _____
1601 Clint Moore Road
Boca Raton, FL 33487-2841

6. If the repairs performed on your modem were covered by the warranty, Boca Research, Inc. will return it prepaid via UPS.

Command Reference

BASIC AT COMMANDS (default values are highlighted)

Command	Description
---------	-------------

AT	Attention characters
ATA	Answer command
A/	Re-Execute last command

Dial Modifiers

Dial	Options	Description
ATD	0-9	DTMF digits
	L	Re-dial last number.
	P	Pulse (rotary) dial. 10 pulses per second.
	T	Touch tone dial (DTMF).
	W	Wait for dial tone for 1-255 seconds. Default is 50 seconds (this value is set by the S7 register).
	,	(Comma) Pause for 0-255 seconds. Default is 2 seconds (this value is set by the S0 register).
	@	Wait for quiet answer.
	!	Initiate hook flash.
	;	Return to command state after dialing.
	^	Disable calling tone.
	S=n	Dial stored number. (See AT&Z). n=0-3.

Command	Description
---------	-------------

Command Character Echo

ATE0	Disables echoing of the commands to the screen.
ATE1	Enables echoing of the commands to the screen. (default)

Switch Hook Control

ATH0	Instructs modem to go on-hook.
ATH1	Instructs modem to go off-hook.

Identification

ATI0	Displays the product identification code.
ATI1	Displays the checksum.
ATI2	Displays ROM checksum as OK or ERROR.
ATI3	Displays the firmware revision level.
ATI4	Reports OEM-defined identifier string.
ATI5	Reports country code.
ATI6	Reports modem data pump model.

Speaker volume

ATL0	Low volume.
ATL1	Low volume. (default)
ATL2	Medium volume.
ATL3	High volume.

Speaker control

ATM0	Disables the modem speaker.
ATM1	Turns speaker on until carrier has been detected. (default)
ATM2	Speaker is always on.
ATM3	Speaker is on when receiving carrier and during dialing, but off during answering.

Command	Description
---------	-------------

Automode enable

ATN0	Requires speed of the connection be that specified by the value of S37.
ATN1	Permits handshaking at any speed supported by both modems. (default)

Return to on line state mode

ATO0	Switches the modem from command mode to on-line mode without dialing.
ATO1	Switches from command mode to on-line mode and initiates an equalizer retrain sequence. d

Mode responses

ATQ0	Enables result codes to be issued to the screen. (default)
ATQ1	Disables result codes to be issued to the screen.

Result code format

ATV0	Numeric format.
ATV1	Verbal format. (default)

Error correction message control

ATW0	Error correction call progress not reported. (default)
ATW1	Call progress reported.
ATW2	Call progress not reported. Connect xxxx message reports DCE speed (e.g., CONNECT 28800).

Command	Description
---------	-------------

Extended result codes

ATX0	Disables monitoring of busy tones unless forced otherwise by country requirements; sends only OK, CONNECT, RING, NO CARRIER, ERROR and NO ANSWER result codes.
ATX1	Disables monitoring of busy tones unless forced otherwise by country requirements; sends only OK, CONNECT, RING, NO CARRIER, ERROR, NO ANSWER and CONNECT XXXX result codes.
ATX2	Disables monitoring of busy tones unless forced otherwise by country requirements; sends only OK, TONE, NO ANSWER and CONNECT XXXX result codes.
ATX3	Enables monitoring of busy tones; sends only OK, CONNECT, RING, NO CARRIER, ERROR, NO DIALTONE, NO ANSWER and CONNECT XXXX.
ATX4	Enables monitoring of busy tones and sends all messages. (default)

Control long space disconnect

ATY0	Disables long space disconnect. (default)
ATY1	Enables long space connect.

Soft reset and restore profile

ATZ0	Restores stored profile 0. (default)
ATZ1	Restores stored profile 1.

Escape Characters

+++	The escape characters are known as +++. They will switch from on-line mode to command mode while preserving the connection with the on line modem.
-----	--

Extended AT Commands

Command	Description
---------	-------------

Data carrier detect (DCD) signal

AT&C0	Forces DCD signal to be on at all times. (default)
AT&C1	DCD on indicates presence of data carrier.

Data terminal ready (DTR) signal. Interprets the ON to OFF transition of the DTR signal from the DTE according to the &Q settings.

AT&D0	&Q0,5,6. DTR ignored. &Q1,4. Modem hangs up; auto answer not affected. &Q2,3. Modem hangs up; auto answer inhibited. (default)
AT&D1	&Q0,1,4-6. Asynchronous escape sequence. &Q2,3. Modem hangs up; auto answer inhibited.
AT&D2	&Q0-6. Modem hangs up; auto answer inhibited.
AT&D3	&Q0,1,4-6. Modem does a soft reset as if the ATZ command were received; &Q2,3. Modem hangs up; auto answer inhibited.
AT&F	Recalls factory defaults. Instructs the modem to use the factory set parameters.

DTE/Modem flow control

AT&K0	Disable flow control.
AT&K3	Enable RTS/CTS (default for data mode)
AT&K4	Enable XON/XOFF.
AT&K5	Enable transport XON/XOFF.
AT&K6	Enable both RTS/CTS and XON/XOFF (default for FAX mode)

Note on Flow Control. XON/XOFF is a software-based flow control method, using standard ASCII control characters to pause or resume data transmission. RTS/CTS pacing, a hardware-based method, uses an electrical signal. Signals are exchanged as follows:

RECEIVER		TRANSMITTER
CTS ON	➔	START SENDING
CTS ON	➔	RTS ON (ready to send)
CTS OFF	➔	RTS OFF (stop sending)

Command	Description
---------	-------------

Select pulse dial make/break ratio

AT&P0	Selects a make/break ratio of 39/61 at 10pps. US and Canada. (default)
AT&P1	Selects a make/break ratio of 33/67 at 10pps. UK and Hong Kong.
AT&P2	Same as 0 except at 20pps.
AT&P3	Same as 1 except at 20pps.

Asynchronous mode

AT&Q0	Direct Asynchronous mode.
AT&Q5	Modem negotiates an error-corrected link. (default)
AT&Q6	Selects asynchronous operation in normal mode (i.e. speed buffering).

RTS/CTS (Request to Send/Clear to Send)

AT&R0	Not supported.
AT&R1	CTS will drop if required by flow control (default).

Data Set Ready (DSR) signal

AT&S0	Causes DSR signal to be active at all times. (default)
AT&S1	Causes DSR signal to be active according to the CCITT specification.

Command	Description
---------	-------------

Test and diagnostics

AT&T0	Terminates any test in progress.
AT&T1	Executes the local analog loopback test.
AT&T3	Executes the local digital loopback test.
AT&T4	Enables the modem to accept a request from a remote modem for a digital loopback test.
(default)	
AT&T5	Instructs the modem to deny a request from a remote modem for a digital loopback test.
AT&T6	Executes the remote digital loopback test.
AT&T7	Executes the remote digital loopback test with a self test.
AT&T8	Executes the remote analog loopback test with a self test.

View Configuration

AT&V	View current configuration and user profile.
------	--

Store user profile. Saves the current configuration into non-volatile RAM as one of two user profiles.

AT&W0	Saves as user profile 0.
AT&W1	Saves as user profile 1.

Designate default user profile

AT&Y0	Selects user profile 0.
AT&Y1	Selects user profile 1.

Stored phone number

AT&Z0=	Stores a 45 digit dial string.
AT&Z1=	Stores a 45 digit dial string.
AT&Z2=	Stores a 45 digit dial string.
AT&Z3=	Stores a 45 digit dial string.

MNP Operation

The V.34 Modem supports all of the preceding classes. The following AT Commands apply to the MNP protocol. Default values are highlighted.

Maximum MNP Block Size. Use this command to transmit smaller blocks of data in a reliable data link connection.

- AT\A0 set maximum block size to 64 characters.
AT\A1 **set maximum block size to 128 characters.**
 (DEFAULT)
AT\A2 set maximum block size to 192 characters.
AT\A3 set maximum block size to 256 characters.

Transmit Break. When this command is entered during a non-MNP connection, a break signal is sent to the remote modem. The length of the break is 100 times the n parameter (1-9) in milliseconds. The default is 3.

AT\B3 **(DEFAULT)**

Modem to Modem Flow Control. Enables or disables modem to modem flow control during a normal mode connection. This command is ignored when error correction is selected.

- AT\G0 **Disables flow control (XON/XOFF) (DEFAULT)**
AT\G1 **Enables flow control (XON/XOFF)**
-

Break Control. Determines the modem response when a BREAK is received from the DTE or the remote modem. The values of the parameters vary based on the three following conditions:

(1) When a break is received from the DTE during NORMAL or MNP mode:

- AT\K0, 2, 4 modem enters command mode without sending a break to the remote modem.
- AT\K1 modem clears the terminal and modem buffers and sends a break to the remote modem.
- AT\K3 modem does not clear the buffers, but sends a break to the remote modem.
- AT\K5 **modem sends a break to the remote modem in sequence with any transmitted data. (DEFAULT)**

(2) When a break is received from the remote modem during NORMAL mode:

- AT\K0, 1 modem clears the terminal and modem buffers and sends a break to the local DTE.
- AT\K2, 3 modem does not clear the buffers but sends a break to the local DTE.
- AT\K4, 5 **modem sends a break in sequence with any data being buffered. (DEFAULT)**

(3) When a break is received from the DTE during DIRECT MODE mode:

- AT\K0,1,3 modem sends a break to the remote modem and enters command mode.
- AT\K2, 4, 5 **modem sends a break to the remote modem. (DEFAULT)**

Error Correction Operating Mode. Selects the operating mode the modem uses while connected.

AT\N0	NORMAL (speed buffering) mode.
AT\N1	DIRECT (pass-through) mode.
AT\N2	RELIABLE LINK mode. Specifies error correction for the modem-to-modem connection
AT\N3	AUTO-RELIABLE LINK mode. Attempts error-correction connection but will fall back to normal mode if unable to establish an MNP link. (default)
AT\N4	LAPM error correction mode.
AT\N5	MNP error correction mode

AT Commands for V.42/V.42bis

The following AT commands apply to the V.42/V.42bis protocol:

Compression Control. Determines whether or not modem will use data compression.

AT%C0	disables data compression
AT%C1	enables MNP5 data compression negotiation
AT%C2	enables V42bis data compression
AT%C3	enables both V.42bis and MNP5 data compression (DEFAULT)

Auto-retrain. Determines whether or not the modem automatically monitors the line quality and requests a retrain when necessary.

AT%E0	disables line quality monitor auto-retrain
AT%E1	enables line quality monitor auto-retrain
AT%E2	enables line quality monitor auto retrain and auto fall back/forward. (DEFAULT)

Report Received Signal Level.

AT%L	009 = -9 dBm, 010 = -10dBm, etc. all the way to 043 (-43 dBm)
------	---

Line signal and noise are determined by the unit of measurement dBm (decibel referenced to one milliwatt). To arrive at a signal/noise ratio, the noise level is subtracted from signal level in dBm.

AT%Q 009 = -9 dBm, 010 = -10dBm, etc. all the way to 043
 (-43 dBm)

Report Line Signal Quality. Returns a "high-order" byte of the calculated EQM ("eye quality monitor"). This can range from 0 to 255. When the value is 8 or greater, the modem will automatically retrain if enabled by the AT%E1 command. The value for a normal connection ranges from 0 to 2 and approaches 8 for a progressively poorer connection. Returns an OK result code.

000 to 007 no retrain

008 to 255 retrain performed if enabled by %E1.

AT+MS Command (Modulation Select)

This extended format command selects the modulation, optionally enables or disables automode, and optionally specifies the lowest and highest connection rates using from one to four subparameters. The command format is:

+MS=<mod>[,<automode>][,<min_rate>][,<max_rate>]]]

The default value as reported by the +MS? command is:

+MS=11,1,300,28800

Note 1: For 14400bps and lower speeds, the Nn command and S37 register can alternatively be used, in which case the +MS subparameters will be modified to reflect the Nn command and S37=x settings. Use of the Nn and S37=x commands is not recommended, but is provided for compatibility with existing communication software. (S37 is not updated by the +MS command).

Note 2: Subparameters not entered (enter a comma only or <CR> to skip the last subparameter) remain at their current values.

Reporting Selected Options

The modem can send a string of information to the DTE consisting of selected options: +MS?

The response is:

+MS:<mod>,<automode>,<min_rate>,<max_rate>

Example: +MS: 11, 1, 300, 28800 (shows default values)

Reporting Supported Options

The modem can send a string of information to the DTE consisting of supported options using the following commands.

+MS=?

The response is:

+MS: (list of supported <mod> values), (list of supported <automode> values), (list of supported <min_rate> values), list of supported <max> rate values)

Example:

+MS: (0, 1, 2, 3, 9, 10, 11, 64, 69, 74), (0,1) (300-28800), (300-28800)

Subparameter Definitions

1. **<mod>** = a decimal number which specifies the preferred modulation (automode enabled) or the modulation (automode disabled) to use in originating or answering a connection. The options are as shown on the following page:

<mod>	Modulation Selected	Possible rates (bps)
0	V.21	300
1	V.22	1200
2	V.22bis	2400 or 1200
3	V.23	1200*
9	V.32	9600 or 4800
10	V.32bis	14400, 12000, 9600, 7200, or 4800
11	V.34	28800, 26400, 24000, 21600, 19200, 16800, 14400, 12000, 9600, 7200, 4800, or 2400 (DEFAULT)
64	Bell 103	300
69	Bell 212	1200
74	V.FC	28800, 26400, 24000, 21600, 19200, 16800, 14400

* For V.23, originating modes transmit at 75bps and receive at 1200bps; answering modes transmit at 1200bps and receive at 75bps. The rate is always specified at 1200bps.

The modem may also automatically switch to another modulation (automode), subject to the following constraints:

- The modem may not be able to automatically switch from the current modulation (specified by <mod>) to some other modulation. For example, there is no standard way to automode from Bell 103 to V.23.
- The DTE may disable automode operation (see <automode>).
- The DTE may constrain the range of modulations available by specifying the lowest and highest rates (see <min_rate> and <max_rate> below).

2. **<automode>**=an optional numeric value which enables or disables automatic modulation negotiation. Options are:

<automode>	Option Selected
0	Automode disabled
1	Automode enabled

The default value is 1, which enables automode. Note, however, there are modulations for which there is no automatic negotiation (e.g., Bell 212 (<mod>=69).

For <automode> = 0 (automode disabled, i.e., fixed modulation):

- a. If <max_rate> is within the rates supported by the selected modulation, the selected rate is that specified by <max_rate>.

Example: +MS=9,0,1200,4800 selects V.32 4800bps fixed rate.

- b. If <max_rate> is greater than the highest speed supported by the modulation specified by <mod>, the starting rate is the highest rate supported by the selected modulation.

Example: +MS=9,0,2400,14400 selects V.32 9600 or 4800bps.

- c. To emulate N0S37=x command sequence to select fixed mode operation, specify the <max_rate> and <min_rate> both to be the same requested speed, and <mod> to be the modulation for that speed.

Example: +MS=11,0,16800,16800 selects V.34 16800bps fixed mode (no comparable S37 command).

+MS=10,0,12000,12000 selects V.32bis 12000bps fixed mode (same as N0S37=10).

For <automode> = 1 (automode enabled; i.e., automatically selected speed and modulation).

- a. If <max_rate> is greater than the highest rate supported by the modulation specified by <mod>, the modem automodes down from the highest rate of selected modulation.

Example: +MS=10,1,1200,24000 selects automoding down from V.32bis 14400bps.

- b. To emulate N1S37=x sequence command, specify the modulation and the rate to start automoding down from using <mod> and <max_rate>, respectively. Set <min_rate> to 300 to allow automoding all the way down to V.21 300bps.

Example: +MS=11,1,300,16800 selects automode starting at V.34 16800bps (no comparable S37 command)

+MS=10,1,300,12000 selects automode starting at V.32bis 12000bps (same as N1S37=10).

3. <min_rate>= is an optional number which specifies the lowest rate at which the modem may establish a connection. The value is decimal-coded in units of bps, e.g., 2400 specifies the lowest rate to be 2400bps. The default is 300 for 300 bps.
4. <max_rate>= is an optional number which specifies the highest rate at which the modem may establish a connection. The value is decimal-coded in units of bps, e.g., 14400 specifies the highest rate to be 14400bps. The default is 28800 for 28800bps.

S-Registers

This section defines the purpose of the modem registers, and sequentially lists the registers and describes their functions. These registers affect various operating characteristics and allow you to obtain information about the modem, as well as test the modem. Each register has a factory-set value, which you can read or change to fit your needs.

Reading a Register Value

To read the current value of a register, type:

AT Sn? [ENTER],

where n is a register number.

AT Sn? Sn? [ENTER] from the command mode.

To read the register values of S0 and S1, type

AT S0? S1? [ENTER].

The modem will display the first register value, a carriage return, the next register value, a carriage return, and OK or 0.

Changing a Register Value

To change a register value, use the Sn command (ATS_n=v), where n is a register number and v is the new value you want to assign to the register. Type:

AT S0=3 [ENTER]

to have the modem automatically answer on the third ring.

The following table lists the modem's registers and their functions.

Reg.	Range	Units	Default	Definition
S0	0-255	rings	0	Auto-answer
S1	0-255	rings	0	Count incoming rings
S2	0-255	rings	43	Escape character value.
S3	0-127	ASCII	13	Carriage return character.
S4	0-127	ASCII	10	Line feed character.
S5	0-255	ASCII	8	Backspace character.
S6	2-255	seconds	2	Wait time for Blind Dialing.
S7	1-255	seconds	50	Wait for carrier after dial.
S8	0-255	seconds	2	Pause time for dial delay.
S9	1-255	seconds	6/10	Carrier detect.
S10	1-255	seconds	14 (1.4)	Lost Carrier to Hang Up Delay.
S11	50-255		95/100	DTMF tone duration (* in one-hundredth second increments)
S12	0-255	seconds	50(1)	Escape code guard time*. (*in one-fiftieth second increments)
S13				Reserved.
S14	Bit Mapped		138(8Ah)	Bit mapped registers.
S15				Reserved
S16	Bit Mapped		0	Modem test options.
S17				Reserved.
S18	0-255	seconds	0	Test timer.
S19				Reserved.
S20				Reserved.
S21	Bit Mapped		4(04h)	Bit mapped registers.
S22	Bit Mapped		117(75h)	Bit mapped registers.
S23	Bit Mapped		54(36h)	Bit mapped registers.

Reg.	Range	Units	Default	Definition
S24	0-255	seconds	0	Sleep Inactivity Timer.
S25	0-255	seconds	5	Asynchronous DTR Delay.
S26	0-255	seconds	1	RTS to CTS Delay Interval.
S27	Bit Mapped		9(09h)	Bit mapped registers.
S28	Bit Mapped		0	Bit mapped registers
S29	0-255	ms	10	Flash Dial Modifier Time.
S30	0-255	seconds	0	Disconnect Inactivity Timer.
S31	Bit Mapped		2	
S32	0-255	ASCII	17(11h)	XON Character.
S33	0-255	ASCII	19(19h)	XOFF Character.
S34-35				Reserved.
S36			7	LAPM Failure Control
S37			0	Line Connection speed

NOTE: Desired sub-V.34 line connection speed. If an invalid number is entered, the number is accepted into the register, but S37 will react as though the default value has been entered. See the +MS command for more modulation selections.

Bits 0-4:

- 0 = **Attempt auto mode connection (DEFAULT)**
- 1-3 = Attempt to connect at 300bps
- 4 = Reserved
- 5 = Attempt to connect at V.22 1200bps
- 6 = Attempt to connect at V.22bis 2400bps
- 7 = Attempt to connect at V.23
- 8 = Attempt to connect at V.32/V.32bis 4800bps
- 9 = Attempt to connect at V.32/V.32bis 9600bps
- 10 = Attempt to connect at V.32bis 12Kbps
- 11 = Attempt to connect at V.32bis 14.4Kbps
- 12 = Attempt to connect at V.32bis 7200bps (ATF7)

Reg.	Range	Units	Default	Definition
S38	0-255	seconds	20	Delay Before Forced Hangup.
S39	Bit Mapped		3	Bit Mapped Registers.
S40	Bit Mapped		104(68h)	Bit Mapped Registers.
S41	Bit Mapped		3	Bit Mapped Registers.
S42-45				Reserved.
S46	136 or 138		138	Data Compression Control.

NOTE: 136 enables error correction with no compression; 138 enables error correction WITH compression.

S48	0, 7, 128		7	V.42 Negotiation.
-----	-----------	--	---	-------------------

NOTE: 0 disables negotiation and proceeds with LAPM; 7 enables negotiation; and 128 disables negotiation and proceeds with fallback action specified in S36. The default for S36 is to attempt an MNP connection.

S49-81				Reserved.
S82	3, 7, 128		128(40h)	Break Handling Option.
S86	0-255		NA	Connection Failure Cause Code.
S91	0 to -15 dBm		10	PSTN Transmit Level.
S92	0 to -15 dBm		10	Fax Transmit Level.

Reg.	Range	Units	Default	Definition
S95	Bit-Mapped		0	Extended Results Codes.

NOTE: Bit values are defined as follows for S95:

0 = CONNECT CODE indicates DCE speed instead of DTE speed.

1 = Append ARQ (automatic repeat request) to verbose CONNECT XXXX result code if protocol is other than none.

2 = Enable CARRIER XXXX result code.

3 = Enable PROTOCOL XXXX result code.

5 = Enable COMPRESSION result code.

Bits 4, 6, and 7 are reserved.

Result Codes

Result Code	Numeric Value	Description
OK	0	Modem successfully executed a command line.
CONNECT	1	Connection made at 300 bps.
RING	2	Modem detected an incoming call.
NO CARRIER	3	Modem lost or could not detect a remote carrier signal within the Register S7 time.
ERROR	4	Modem found an error in the command line.
CONNECT 1200	5	Modem established a connection 1200 at 1200bps.
NO DIALTONE	6	Modem did not detect a dial tone within 5 seconds after going off-hook.
BUSY	7	Modem detected a busy signal.
NO ANSWER	8	Five seconds of silence was not detected when using the @ command in the dial command line.
CONNECT 0600	9	Modem established a connection at 600 bps.
CONNECT 2400	10	Modem established a connection at 2400 bps.
CONNECT 4800	11	Modem established a connection at 4800 bps.
CONNECT 9600	12	Connection made at 9600 bps.

Result Code	Numeric Value	Description
CONNECT 7200	13	Connected as data modem during an answer.
CONNECT 12000	14	Connection made at 12000 bps.
CONNECT 14400	15	Connection made at 14400 bps.
CONNECT 19200	16	Connection made at 19200 bps.
CONNECT 38400	17	Connection made at 38400 bps.
CONNECT 57600	18	Connection made at 57600 bps.
CONNECT 115200	19	Connection made at 115,200 bps.
CONNECT 75TX/1200RX	22	Modem returns this result code when upon establishing a V.23 originate connection when the modem has been instructed to report the DTE speed to the DTE upon connecting.
CONNECT 1200RX/75RX	23	Modem returns this result code when upon establishing a V.23 answer connection when the modem has been instructed to report the DTE speed to the DTE upon connecting.

Result Code	Numeric Value	Description
DELAYED	24	For X4; when a call fails to connect and the number dialed is 'delayed' due to country blacklisting requirements.
BLACKLISTED	32	For X4; when a call fails to connect and the number dialed is considered 'blacklisted'.
FAX	33	A fax modem connection is established.
DATA	35	A data modem connection is established.
CARRIER 300	40	Carrier rate of 300 bps.
CARRIER 1200/75	44	V.23 backward channel has been detected.
CARRIER 75/1200	45	V.23 forward channel has been detected
CARRIER 1200	46	Carrier rate of 1200 bps.
CARRIER 2400	47	Carrier rate of 2400 bps.
CARRIER 4800	48	Carrier rate of 4800 bps.
CARRIER 7200	49	Carrier rate of 7200 bps.
CARRIER 9600	50	Carrier rate of 9600 bps.

Result Code	Numeric Value	Description
CARRIER 12000	51	Carrier rate of 12000 bps.
CARRIER 14000	52	Carrier rate of 14400 bps.
CARRIER 16800	53	Carrier rate of 16800 bps.
CARRIER 19200	54	Carrier rate of 19200 bps.
CARRIER 21600	55	Carrier rate of 21600 bps
CARRIER 24000	56	Carrier rate of 24000 bps
CARRIER 26400	57	Carrier rate of 26400 bps.
CARRIER 28800	58	Carrier rate of 28800 bps.
COMPRESSION: CLASS 5	66	The modem has connected in MNP class 5 and COMPRESSION message reporting has been enabled.
COMPRESSION V.42bis	67	The modem has connected in V.42bis and COMPRESSION message reporting has been enabled.

Result Code	Numeric Value	Description
COMPRESSION: 69 NONE		The modem has connected without data compression and COMPRESSION message reporting has been enabled.
PROTOCOL: 76 NONE*		Modem has connected without any form of error connection.
PROTOCOL: 77 LAPM*		Modem has connected in the V.42 LAPM mode of error correction.
PROTOCOL: 80 ALT*		Modem has connected in the MNP mode of error correction.
PROTOCOL: 81 ALT* CELLULAR		Modem has connected in the MNP10 mode.
* PROTOCOL message reporting has been enabled.		
+FCERROR	+F4	Fax carrier error.

Glossary

A

algorithm. A formula or procedure which employs various methods defining how data is to be used to give a prescribed result.

analog signals. Signals which can vary over a continuous range (e.g., the human voice over conventional telephone lines). Analog circuitry is more subject to distortion and noise, but it is more capable of handling complex signals than are digital signals which can have only discrete values.

ARQ. Automatic Retry ReQuest for retransmission. A type of communications link where the receiver asks the transmitter to re-send a block of data when errors are detected.

ANSI. American National Standards Institute. A non-profit, private industry association which governs most USA-standards setting agencies.

ASCII. Acronym for American Standard Code for Information Interchange. ASCII is an ANSI character set. The standard ASCII character set consists of 128 decimal numbers (0-127) for letters of the alphabet, numerals, punctuation marks, and common special characters. The extended ASCII character set extends to 255 characters and contains special mathematical, graphics, and foreign characters.

asynchronous communications. A method of transmission in which one character is sent one bit at a time; also referred to as serial transmission.

automode. Capability to automatically select the highest possible line speed. Factors for highest possible line speed include: ITU-TSS compliance, common capabilities of both modems and telephone line quality.

B

Bell standards. Refers to the U. S. modulation protocol standards developed by the former AT&T Bell Systems such as Bell 103 (300bps transmission) and Bell 212A (1200bps transmission).

bit-mapped registers. An S-register which contains multiple bit-oriented values. Example: the value of S22 is the sum of the bit values which you select (bits 0-1: speaker volume/value: 0-3; bits 2-3: speaker control/value: 0-3; bits 4-6: limit result codes/value: 0, 4-6, 7).

blind dialing. An automated process whereby the modem goes off-hook and dials without waiting for a dial tone. This is prohibited in many countries.

block transfer control. Determines whether or not the modem uses block or stream mode during an MNP connection. In stream mode, MNP sends data frames in varying length. Block mode sends fixed data frames of 256 characters and is selected with the MNP-based \L command.

bps. bits per second.

break handling. Determines how the modem responds when a BREAK signal is received from either the DTE (Data Terminal Equipment or computer/terminal) or the remote modem. This is controlled by the MNP-based AT extended command \K. A break signal is represented on the communications line by a steady space signal for a significant length of time. Break signals may be activated from the keyboard by pressing the BREAK key or the control (CTRL) and C keys.

C

CCITT. Consultative Committee for International Telephone and Telegraph. This advisory organization is part of the ITU (International Telecommunication Union) which is an agency of the United Nations. Organization recently renamed International Telecommunications Union-Telecommunications Standards Sector (ITU-TSS)

command mode. The modem is in command mode when it is turned on or reset, when it loses its connection to a remote modem, when it is in on-line mode, or when escape characters (+++) are typed. To transmit data, the modem must be in data mode. The modem does not transmit data when in command mode.

communications protocol. A set of procedures which controls how a data communications network operates.

D

DCD. Data Carrier Detect. Indicates to the terminal device that the modem is receiving a valid carrier signal from a remote modem. The carrier is a tone at a specified frequency.

DCE. Data Communications Equipment. The local and/or remote modem. A DCE is usually connected to a DTE.

DTE. Data Terminal Equipment. The computer or terminal, either local (yours), or the remote (the one you're communicating with). A DTE is usually connected to a DCE.

DTR. Data Terminal Ready. The computer issues this signal to the attached modem indicating that it is ready to receive data.

data compression. A technique that examines transmitted data for redundancy and replaces strings (groups) of characters with special codes which the receiving modem interprets and restores to its original form. Transmission of compressed data results in shorter connect times and hence cost savings for connect charges. Data compression is sometimes called "source encoding".

data mode. The modem is in data mode when a connection has been established with a remote modem and sends a CONNECT response confirming the connection. User data may then be transmitted or received.

dial modifier. Dial modifiers are special characters appended to the ATD command which instruct the modem how to place a call.

digital signal. A discrete signal which can only take on one of several (usually only two) discrete levels in contrast to analog signals which can take a continuous range of levels.

E

error detection and correction. The transmitting modem attaches a special pattern (called a frame check sequence) calculated according to a prescribed algorithm from user-defined data to the end of a block of data. The receiving modem performs the same algorithm and compares it to the one with the transmitted data. If these match, then the block of data has been received correctly. If not, the block of data is re-transmitted until no errors are detected.

escape sequence. Also referred to as the escape command. This special command is entered as three plus symbols (+++) and places the modem in command mode and interrupts user data transmission, but does not terminate the data connection. This allows the entering of commands while the connection is maintained.

extended AT-command. Extended commands were developed to provide greater functionality and control over modem operations than is available from the basic AT command set.

F

fax mode. The modem is in fax mode when, through use of fax communications software, it can send and receive faxes, print and display fax files, convert files to fax-files, and set certain fax-related features. Note: the modulation protocol used by the modem in fax mode is also different from the usual data mode modulation.

flow control. Compensates for the difference between the rate at which data reaches a device and the rate at which the device processes and transmits. This is controlled by the extended AT command &K. The two common types of flow control are RTS/CTS signaling (a hardware based method, employing an electrical signal) and XON/XOFF (a software-based method using standard ASCII control characters to pause or resume transmission).

full-duplex. Two-way simultaneous transmission between modems, which may occur via a four-wire circuit on a leased line, or with a two-wire connection when the frequency bandwidth is divided into two distinct channels, or when echo cancellation is employed (e.g., Bell 103, 212, and V.22 use frequency division, while V.32 uses echo cancellation).

G

guard tone. Guard tones are used in the United Kingdom and other countries. This requires that the modem transmit an 1800-Hz tone after it sends an answer tone. The guard tone is controlled by the &G command. Guard tones are not used in the U.S.A.

H

half-duplex. Signal flow in both directions, but only one way at a time with each modem alternating between send and receive.

Hayes-compatible. Hayes Microcomputer Products, Inc. developed the AT command set which has become a de facto industry standard. Hayes commands are always initiated with an AT (attention code) prefix.

hook flash. The dial modifier "!" causes the modem to go on-hook (hang-up) for one-half second. Also controlled by the ATH command.

L

LAPM. Link Access Protocol Modem. A V.42 ARQ type of error correction protocol which is controlled by S-Register 46, where LAPM may be activated with or without V.42bis data compression.

leased line. Also referred to as a private line. A leased line is obtained from a communications company (carrier) to provide a transmission medium between two points. The line consists of a permanent dedicated circuit between two points, or to set of previously arranged points. The cost of the line is usually based on the distance between locations. This is in contrast to switched or dial-up lines, which can be connected to any point on the network.

line modulation. The means by which a carrier is varied to represent a signal carrying information. In a modem, the user's digital data is used to modulate the modem's transmitter's carrier or carrier to allow the digital signal to be carried over analog facilities.

long space disconnect. Determines whether or not modem disconnects when it receives a continuous break from a remote modem. Controlled by the ATY command.

loopback tests. There are four types of loopback tests which are as follows: (1) the local digital loopback tests the operation of the DTE, including whether or not data is leaving the terminal or computer port; (2) the local analog loopback tests the digital and analog circuits of the modem; (3) the remote digital loopback checks the operating condition of the line and remote modem; (4) the remote analog loopback tests the line to the remote modem.

M

MNP. Microcom Networking Protocol. A series of data communications protocols developed by Microcom for full-duplex, error-free communications.

make/break ratio. The &P command controls the ratio of the off-hook (make) to on-hook (break) interval used by the modem when it pulse dials. &P0 selects a 39%/61% make/break ratio for use in the U.S. &P1 selects a 33%/67% make/break ratio for use in the United Kingdom and Hong Kong. The &P command is NOT allowed in some countries.

modulation handshake. Also referred to as Automode Enable and is controlled by the ATN command. This determines whether or not the modem must connect at a particular speed, or allow connection at any speed supported by both modems.

N

negotiation fallback. Controlled by S-Register 36 as part of the V.42 protocol. Setting this register indicates what action to take when a desired connection cannot be made (e.g., hang-up, direct mode connect, normal mode connect).

non-volatile RAM. Also NVRAM. Random access memory whose data is retained when power is turned off. This is especially useful for modems to store user-defined default configuration settings and frequently used telephone numbers. This information would be loaded into modem RAM at power-up.

O

on-line state. Same as data mode. To transmit or receive data, the modem must be in the on-line state. When placing a call, the modem is put on-line with the dial command.

P

PBX. Private Branch Exchange. A telephone switch at a customer site.

pulse dialing. Also referred to as rotary dialing, i.e., dialing with the older-style rotary dial wheel. The dial modifier ATP sets the modem to pulse dialing, which is the default method as opposed to tone dialing (push-button touch-tone) which is enabled with ATT. All telephone exchanges will accept older-style pulse dialing and most exchanges will accept modern tone-dialing. Tone dialing is faster and more reliable since mechanical relays and their inherent failure mechanisms are avoided.

R

result code. A response sent by the modem after executing a command. The response reports the modem's status or the progress of a call and can take the form of either digits (numeric) or words (verbose). Issuing a V1 command enables word responses. A V0 (V-zero) command enables numeric responses. The Q1 command disables their use entirely. Example: "OK" (word), or 0 (numeric) indicates that the modem successfully executed a command.

retrain. An adjustment process performed when one of the modems detects signal distortion or line noise which threaten data integrity.

RTS/CTS. Request to Send/Clear to Send. RTS and CTS are two control signal lines between the modem (DCE) and terminal (DTE) which allow the terminal to control the flow of information. See also flow control.

S

sleep inactivity timer. Determines the length of time the modem operates in normal mode with no activity before entering low-power "sleep" mode.

split-speed direction. Determines which direction (transmit or receive) has the 75bps channel and which has the 1200bps channel, but is only active if the \W command is set to 1. Used with V.23 modulation only.

standard AT-command. The basic AT command set, originated by Hayes Microcomputer Products, Inc.

synchronous clock source. Applies to synchronous modem operations and is set with the &X command. The command specifies the clocking source referred to as the transmit signal element timing. This can be controlled by either the modem or the terminal.

synchronous communications. A method of transmission in which data bits are sent continuously at the same rate under the control of a fixed frequency clock signal.

T

touch-tone dialing. Push-button tone dialing as used on contemporary phone sets. The dial modifier ATT sets the modem to "tone" mode. Tone dialing is faster and more reliable than older-style pulse dialing.

X

XON/XOFF. XON and XOFF are the names of two different control characters. See also flow control.

Acknowledgements

The Complete Modem Reference. Gilbert Held. John Wiley & Sons, Inc.
Upgrading and Repairing PCs. (Second Edition). Que Corporation.

Index

A

AC wall socket 16
Asynchronous Mode 63
AT Command Reference 58-84
Automode Enable 60

B

Bell standards 42
BBS 55

C

CCITT 42
COM ports 26
COMCHECK 26-27
Command/Protocol Reference 40-43
Communication Settings 26
Compatibility 49
Compliance Information 50-53
Connecting the Phone Line 15, 29
Contents of Your Package (external) 13
Contents of Your Package (internal) 25
Control Long Space Disconnect 61

D

Data Carrier Detect 62
Data Communication Protocols 42
Data Terminal Ready 62
Data transmission rates 10
Default COM/IRQ 27
Dial Modifiers 58
Dial Stored Number 58
DTE/Modem Flow Control 62

E

Echo command 36
Electronic BBS 55
Error Message Control 60
Escape Characters 61
Extended AT command for V.42/
V.42bis 43, 68
Extended AT command for MNP 43, 65
Extended AT command sets 40, 62-64
Extended Result Codes 61

F

Fax Data Rate 49

Fax Modulation Protocols 49
FCC Requirements 5, 50-52
Features 9

G

Glossary 85-91
Group III send and receive fax
capability 9

H

Hardware Diagnostics 44-48
Hayes 'AT' command set 9, 40, 58-84
Hook flash 51

I

Initialization (INIT) string 11
Initiate hook flash 58
Installation Hints 11
Internal Installation 25-34
Interrupt-sharing 26
IRQ settings 26

L

LED Status Indicators 49
Local Analog Loopback Test 44
Local Analog Loopback Test with Self-
Test 45

M

Make/Break Ratio 63
Microcom Networking Protocol 42
MNP 42, 65-67
Mode Responses 60
Modem Data Rate 49
Modem Modulation Protocols 49

O

On-Line State 60
Operational Requirements (external) 14

P

Pause 58
phone jack types 5
Physical and Electrical
Characteristics 49
Preparing the Modem (external) 16
Pulse (rotary) dial 58

Q

Quick Start! 6, 7

R

Remote Digital Loopback Test 46-47

Remote Digital Loopback Test with Self-test 47-48

Restore Profile 61

Result Code Format 60

Return Merchandise Authorization 56

Return to command state 58

Ringer equivalence number 51

RJ-11 cable 17, 29

S

S-Registers 41, 75-79

Servicing Your Boca Product 55-57

speaker volume control 59

Store phone number 58

T

Technical Specifications 49

Test and Diagnostics 64

Testing the Connection (internal) 34

Testing the Connection (external) 22

Touch Tone (DTMF) dialing 58

Troubleshooting 35-39

V

"V-Dot" standards 42-43

V.42 /V.42bis 68-69

W

Wait for dial tone 58

Wait for quiet answer 58

Warranty Information 54

WARNING/ATTENTION

#1"CAUTION: THIS MODEM CARD IS INTENDED TO BE INSTALLED IN CSA CERTIFIED EQUIPMENT IN THE FIELD BY THE USER IN THE MANUFACTURER'S DEFINED OPERATOR ACCESS AREA. CHECK THE EQUIPMENT OPERATING/INSTALLATION INSTRUCTIONS AND/OR EQUIPMENT MANUFACTURER TO VERIFY/CONFIRM IF YOUR EQUIPMENT IS SUITABLE FOR USER-INSTALLED APPLICATION CARDS."

"ATTENTION: CETTE CARTE MODEM EST DESTINEE A ETRE INSTALLEE PAR L'UTILISATEUR, SUR PLACE ET A L'INTERIEUR DE LA ZONE DEFINIE PAR LA FABRICANT, DANS UN APPAREIL CERIFIE CSA. CONSULTER LE MODE D'EMPLOI OU LE FABRICANT DE L'APPAREIL POUR VERIFIER OU CONFIRMER SI L'UTILISATEUR PEUT Y INSTALLER LUI-MEME DES CARTES PERIPHERIQUES."


#2"CAUTION: ALWAYS DISCONNECT MODEM BOARD (THE ONE WITH THE TELEPHONE/PLUG JACK) FROM THE TELEPHONE SYSTEM WHEN INSTALLING OR WHEN COVERS ARE REMOVED FROM THE HOST PRODUCT."


"ATTENTION: TOUJOURS DEBRANCHER LA LIGNE TELEPHONIQUE DE LA CARTE MODEM (MUNIE D'UNE PRISE OR D'UNE FICHE) AVANT DE PROCEDER A L'INSTALLATION DANS L'APPAREIL OU LORSQUE LE COUVERCLE DE CELUI-CI EST RETIRE."


#3"CAUTION: APPLY THE ENCLOSED ADHESIVE WARNING LABEL TO THE OUTSIDE OR INSIDE OF THE EQUIPMENT ENCLOSURE ADJACENT TO THE MODEM CARD."

"ATTENTION: APPOSER L'ETIQUETTE AUTOCOLLANTE DE MISE EN GARDE CI-INCLUSE SURE LE PAROI EXTERIEURE OU INTERIEURE DU BOITIER DE L'APPAREIL PRES DE LA CARTE MODEM."











Manual Part No. 9438
Rev. 3.0